



## Model 1160-ACKIT Battery Eliminator and Magnetic Stand for 116X / 7X / 8X Series Safety Lights

INS-1160ACKIT-12

**CAUTION:** DO NOT use in explosive atmospheres, near flammable liquids, or where explosion proof lamps are required  
DO NOT use in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the hand-lamp

**CAUTION:** For Light Duty Use Only

**WARNING:** NOT FOR USE ABOVE HAZARDOUS LOCATIONS

Thank you for purchasing this Nightstick flashlight. Save these instructions. Please read these instructions before using your flashlight.

### INCLUDED IN THE KIT


- Battery eliminator module
- AC power adapter
- Large magnet base

Light not included



### INSTALLING THE BATTERY ELIMINATOR

The battery eliminator accessory is used to power the NSP-116X / 7X / 8X series safety lights without the use of four AA batteries. The primary application is for product showcase and display purposes.



The battery eliminator module is powered by a 120V AC wall adapter.

1. Slide off the battery compartment door and remove all batteries from the safety light.
2. Connect the power adapter plug into the battery eliminator module socket.
3. Install the battery eliminator module into the battery compartment. The module is keyed and will only fit one way.
4. To hold the battery eliminator module in place, install one AA battery in the slot next to power adapter plug.
5. Route the power cord toward the top of the battery compartment and install the sliding battery door. **THE BATTERY DOOR WILL NOT CLOSE COMPLETELY. DO NOT USE EXCESSIVE FORCE OR THE CORD WILL BE CUT.**
6. For a stand-up counter display, install the safety light into the large magnetic base.
7. Plug the power adapter into a 120V AC outlet. The safety light is now ready for use. Activate the light functions as needed.

### SAFETY

**CAUTION BRIGHT LED RADIATION: AVOID DIRECT EYE EXPOSURE.** The light is a Class 2 LED product per IEC 60825-1 Edition 1.2.2001.


- Do not use this FLASHLIGHT in explosive or hazardous areas.

### OPERATING THE LIGHT

All models have two body switches that control the flashlight and the safety light. The flashlight and safety light functions can be operated independently and together.

Flashlight  
Momentary or constant  
Lampe de poche  
Momentané ou constant  
Punto de Luz  
Momentâneo o constante

Safety light  
Lumière de sécurité  
De luz de seguridad



### Models 1162 / 1164 / 1166 / 1168

#### Safety Light

1162-red, 1164 -blue, 1166-white, 1168-amber

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the safety light. Press for full power.
3. Press again for half-power. Press again to activate flashing safety light. Press again for off.

### Models 1170 / 1172 / 1176 / 1178 /1180 /1182

#### Safety Light

1170-blue/red, 1172-white/red, 1176-white/amber, 1178-white/blue, 1180-amber/green, 1182-blue/green

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the safety light. Press for constant (non-flashing) safety light. Press again to activate alternating flasher. Press again for off.

### Model 1174

#### Safety Light

1174-amber

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the flood /safety light. Press for floodlight. Press again to activate flashing amber light. Press again for off.

### WARRANTY

#### Limited Lifetime Warranty

Product is warranted to be free from defects in workmanship and materials for the lifetime of the original owner. Includes the housing, lenses, electronics and switches. Batteries, normal wear and abuse are excluded.

#### Not Covered

Consequential damages, incidental damages or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, which may vary from state to state.

#### Warranty Claims - USA

Contact Bayco for USA warranty claims. Call 800-233-2155 or email [cs@baycoproducts.com](mailto:cs@baycoproducts.com) and Bayco Customer Service will provide a Return Goods Authorization (RGA) to facilitate rapid warranty action. After receiving the RGA, send the product (shipping prepaid) to BAYCO • 640 S. SANDEN BLVD • WYLIE, TEXAS • 75098. Include a dated proof of purchase and a brief description of the defect with your name, address and phone number. Your product will either be repaired or replaced at the option of Bayco and returned as soon as practical, but no later than 45 days after being received by Bayco.

#### Warranty questions and international claims

If you live outside the USA or have questions about this warranty or an inquiry about other Bayco products contact BAYCO • 640 S. SANDEN BLVD • WYLIE, TEXAS • 75098 or call 800-233-2155